

Start Up

I, Turn on 2 switches

2, Turn on Ni body

3, Turn on INSCOPER controller

4, Turn on PC and log in with User ID

Note: Inscoper Box should show green light before you start the software





For Phase imaging

Suitable Objective: 100X/1,45 Ph3 Take ND filter out to increase light intensity Move condenser manually to plate ph3

To align: Place 10X objective, close the shutter (#1) until you see the edge Move the Condenser height until the edge is sharp Center with the screws (#2)







Phase contrast alignment (1/2): Procedure

Figure 4 - Phase Contrast Objective



https://www.microscopyu.com/techniques /phase-contrast/phase-contrastmicroscope-configuration 1- Choose either the 10x, 20x or 40x objectives, as this procedure won't work with higher magnification



2- Focus on the sample and keep it fixed during the whole procedure



5- Centre the iris



3- Close the stop-field iris



6- Open the iris slightly more than the field-of-view



https://zeiss-campus.magnet.fsu.edu/articles/basics/practical.html



4- Adjust the

condenser hight

to get a clear

image of the iris



- u ×





Image window:

Display tools:

*	You can move inside the live image by drag-and-drop
(Ħ	You can select this option to add some ROI or make some crops on their live images
	You can choose this option to set the contrast automatically or manually. If it is manually, adjust the blue sliders on top of the camera view.
::	Press this button to switch to full screen mode. To close this mode, press this button again or click on the cross in the top-right corner.
	You can change the LookUp Table (LUT) in real time using this option. You have 3 options: LUT IT with one color eset LUT

Pixel indicator showing in red the overloaded pixels **Inscoper ratiometric** dedicated to ratiometric images visualization Conventional multicolor LUT as "fire", "physics", etc...





Acquisition window- sequences

TINSCOPER Project Settings ? Support	Expert Mode
Configuration Acquisition	Project Name Project 2024-10-31
Camera Settings	Sequence 1 Take Image Config Add Show All
Number of loop 1 Add Sequence	Remove All
Sequence 1 Take Image Time20 Z-Stack1	Copy 8
Sequence 2 Take Image	🔵 💉 💽 🛞
You can define loops to repeat the sequences	You can copy one sequence and only change the parameters modified. Quicker than starting new sequence



Acquisition window-Time





Acquisition – define multi positions, using PFS offset



Acquisition – define multi positions, using Abs Z position



Acquisition – Tiling



Acquisition – Define Tile



Confirm Cancel

Tiling with Focus map



INSCOPER- Acquisition- Stage experiment: Define well plate (Auto position list) !Only using Air Objectives!

Set		If you have a well-plate, click on this button to select the wells you		TINSCOPER DiFile 🏟 Settings (?) Support	rt	Uber Mode - a ×
Set		are intereste	a in.	Configuration Acquisition		Project Name 🖉 Michail Leat
Add position	Add Position	Add a positio	on manually and enter its coordinates.	Camera Settings C Wideled Execute (ma) Binning Advanced Source (Source) Camera Settings C (Source) Source (Sourc		Calibration Three ZDC One shull ZDC Continuous Contin
Remove All	Remove All	Delete all the	e positions.	Comment	Well F Snap 4 Chang Projec	Display settings Plate Editor % Use Veil Plate Editor ye Peasword Name
 ••• 	Move To	Move to the :	selected position.	a status	C Tiff Na Prefer	Mame X Size 12 IV Specific (um) 0000 Interaction V Size 8 IV Specific (um) 9000 Interaction Interacti
Сору	Сору	Copy the req	juired coordinates.			Well Height (unit) 5
Get	Get	Get the curre	ent coordinates of the stage.	424) pri		A intensity
×	Delete	Delete the se	elected position.			Brightfield Jamp M 1L Shutter Called Source (Concerned on the concerned on the concer
	I					
Myl	/Plate 🗸	Choose Your Plate	Select the well-plate you wish to use in the drop-down list.			
		Select	Click on this button to select the wells you need.	Fin 400	Crop Image	Go To Acquilition
	~•	Move To	Move to the selected well.	2. Positions		0 3
	Get	Get	Get the coordinates entered on the well-plate.	Supported plate MyPlate	✓ 8 9 10	
Gen	nerate Random Points	Generate Random Points	By checking this box, the interface will choose several random points on the well-plate. If you check this box, be sure to enter the following information:			0 0 0rigin 0 0 0 Get
		th th	e number of points, reminimum distance.	•0000000		Generate Random Points
	Cancel	Cancel	Click on this button to go back to the manual positions.	EO 0000000 FO 0000000		
	Add	Add	Add the positions you have chosen to the previous ones.	© 0000000 #0000000		
	Clear & Add	Clear & Add	Delete all the previous positions and add the selected ones.			Cancel Add Clear & Add



Acquisition – Multi channel



Acquisition – start experiment

Data Processing and Charts RAW DATA	
Save Acquisition You can save directly to your folder. in RAM on Disk	Total images 16 Total size 33MB Minimal duration
C:\Users\LocalAdmin\Desktc Format All in One	00h00min00s320ms
Metadata Format All in One 🗸	Start Acquisition



Visualization



Visualization





Metadata: you can filter to check specific parameter

Visualization-Tag

TIN SCOPE	R 🗅 File	Settings (?) Si	upport					User Mode
Configuration	Acquisition	Visualization Visualization					Project Name	Project 2023-07-20 Open In Explorer
	Min	Direction Contract DOD Average : 627 23 Max : 9922 OD			∨ Filters			Metadata Taq
					Selected Image set	CH_TILING V Image Processing		Edit
		÷.		2	Charts 🎝 🗙	Sequence		Filter Value
					Total : 1	1/1 0-1	Export : Video Stack	OrcaFlash4-INTERNAL FRAM 9.999362446665053 RCM1-Field Of View X 2048 RCM1-Field Of View Y 2048 OrcaFlash4-SUBARRAY HPC:0 OrcaFlash4-SUBARRAY HPC:0
					You car			OrcaRash4-OUTPUT TRIGGE READOUT END OrcaRlash4-SUBARRAY HPO:0 OrcaRlash4-SUBARRAY HPO:0 OrcaRlash4-SUBARRAY HPO:0 OrcaRlash4-IMING INVALID-0.1 OrcaRlash4-IMING EDETECTC 6-5
			• 0-					ImageType SEQUENCE Microscope-ZDC_Offset 0 RCM1-Laver 3 Selected 1 ChannelIndex 0 RCM1-Scanner Phase Y -1
			. 8					OrcaRash4 OUTPUT TRIGGEEDGE RCMI-Scanner Phase X -1 OrcaRlash4-OUTPUT TRIGGEALL VIEWS RCMI-RCM Type RCM 1.1 Cooled_pC4000-D Shutter false
								Exposure ms 100.00638000000001 Orcaflash4-OUTPUT TRIGGE READDOUT END Orcaflash4-ENTPRE FRAMEE 5388608 Orcaflash4-EXTRACTION MCOFF RCM1-Laser 2 Polarity 1
								Time,0 TimeRelative,0 0 Prior,Proscanil,XYStage-X-Av-2.3353E7 Microscepe-CoverSilip,Positio4245130 Time,0 0 OrcaFlash4-OUTPUT TRIGGEEDGE
		+	234.73 µm					Microscope-Objective 100X oil OrcaHash4-IRIGGER POLARI POSITIVE OrcaFlash4-SENSOR COOLET REDY PixelSizeUm 0.06018518518518518 MIMI-Unter Scon 2 -0.11
								RCM1-Songerstan Y 50.13 RCM1-Offret Scan X 60.42 RCM1-Laser 4 Analog Out 4 OrcaFlash4-INTERNAL LINE I 9.74436090225564E-6 RCM1 Laser 3 Power 80
						<		OrcaFlash4-IMAGE DETECTC 2018 Cooled. pF4000: A Shutter false OrcaFlash4-IMAGE ROWBYT 4096 OrcaFlash4-IMAGE TOP OFF:0

Shut down

I, Save your data and close software and computer. Save data to BULK folder. Data is erased from local folder regularly

2, Clean up:

2,1, lower the objective, only then remove sample.2,2, clean with dry and isopropanol wipe2,3, switch to lowest Mag obj (10X)

3, Turn off INSCOPER BOX

4, Turn off Nikon controller

5, Turn off 2 main switches

Need help/advice?

Contact: Michal: <u>M.Shemesh@tudelft.nl</u> Wiel: <u>W.H.Evers@tudelft.nl</u>

